How to Replace an Auto Oven SafePack

Products

Suma Auto Oven Clean

Suma Auto Oven Rinse Aid

1

When SafePack is empty, twist the connector to disconnect.

2

Remove & dispose of empty pack.

3

Tear perforated lid on the new container to release neck.

4



Place open SafePack container onto the rack

5



Ensure the pin on the cap aligns with the notch on the connector.

6

Attach the connector to the SafePack container with a push & twist

www.diversey.com

© 2018 Diversey, Inc. All Rights Reserved. 71020 en 08/18

Check SDS for detailed information